

SIMATIC NET

Industrial Wireless LAN SCALANCE W778-1 / W738-1

Operating Instructions

Introduction	1
Safety notices	2
Security recommendations	3
Description of the device	4
Installation and removal	5
Connection	6
Maintenance and cleaning	7
Upkeep and maintenance	8
Technical specifications	9
Dimension drawing	10
Approvals	11

MSN65-W1-M12-E2

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

DANGER

indicates that death or severe personal injury **will** result if proper precautions are not taken.

WARNING

indicates that death or severe personal injury **may** result if proper precautions are not taken.

CAUTION

indicates that minor personal injury can result if proper precautions are not taken.

NOTICE

indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified persons are those who, because of their training and experience, are familiar with the installation, assembly, commissioning, operation, decommissioning and disassembly of the product and can recognize risks and avoid possible hazards.

Proper use of Siemens products

Note the following:

WARNING

Siemens products may only be used for the application described in the catalog and the associated usage information. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens Aktiengesellschaft. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Introduction	5
1.1	Purpose of the operating instructions	5
1.2	Scope of validity	5
1.3	Supplementary documentation	5
1.4	Service & Support	6
1.5	Cybersecurity information	7
1.6	Firmware	7
1.7	Open source license conditions	8
1.8	Error/fault	8
1.9	Decommissioning	8
1.10	Recycling and disposal	8
1.11	Marken	8
2	Safety notices	9
3	Security recommendations.....	11
3.1	Security recommendations.....	11
3.2	Available interfaces.....	17
3.3	Available services.....	18
4	Description of the device	21
4.1	Structure of the type designation	21
4.2	Device view	22
4.3	Components of the product	22
4.4	Accessories	23
4.4.1	Installation	23
4.4.2	PLUG	23
4.4.3	Industrial Ethernet	24
4.4.4	Power supply	25
4.4.5	Flexible connecting cables, antennas and accessories	25
4.4.5.1	Flexible connecting cables	25
4.4.5.2	Lightning protection	26
4.4.5.3	Terminating resistor	27
4.4.5.4	Cabinet feedthrough	27
4.4.5.5	Antennas	27
4.5	LED display	30
4.6	Reset button	34

4.7	PLUG	36
5	Installation and removal	39
5.1	Safety notices for installation	39
5.2	Types of installation	42
5.3	Wall mounting	42
5.4	Installation on a DIN rail	43
5.4.1	Installation with the DIN rail mounting adapter	43
5.4.2	Mounting with bracket support	45
6	Connection	49
6.1	Safety when connecting up	49
6.2	Power supply	53
6.3	Ethernet	55
6.4	Antenna connector	56
6.5	Replacing the PLUG	58
6.6	Grounding	59
7	Maintenance and cleaning	61
8	Upkeep and maintenance	63
8.1	Device configuration with PRESET-PLUG	63
8.2	Restoring the factory settings	65
8.3	Firmware update via WBM or CLI not possible	66
9	Technical specifications	69
10	Dimension drawing	73
11	Approvals	75
	Index	77

Introduction

1.1 Purpose of the operating instructions

Based on the operating instructions, you will be able to install and connect the SCALANCE device correctly. The instructions are aimed primarily at planning, commissioning, maintenance and service personnel.

The configuration and the integration of the device in a network are not described in these instructions.

1.2 Scope of validity

These operating instructions cover the following products:

Product	Article numbers	Certification ID
Access points		
SCALANCE W778-1 M12	6GK5778-1GY00-0AA0 6GK5778-1GY00-0AB0 (US)	MSN65-W1-M12-E2
SCALANCE W778-1 M12 EEC	6GK5778-1GY00-0TA0 6GK5778-1GY00-0TB0 (US)	MSN65-W1-M12-E2
Ethernet client module		
SCALANCE W738-1 M12	6GK5738-1GY00-0AA0 6GK5738-1GY00-0AB0 (US)	MSN65-W1-M12-E2

These operating instructions apply to the following firmware version:

- SCALANCE W700 IEEE 802.11n Firmware as of version V6.6

Definition

An access point is a node in a WLAN that also performs administrative functions in the network and, for example, provides client modules with a connection to wired networks, to other client modules in the same wireless cell or in other wireless cells.

1.3 Supplementary documentation

Documentation on the Internet

You can find the current version of the documents on the Internet at (<https://sieportal.siemens.com/su/bjSDr>).

Enter the name or article number of the product in the search filter.

Documentation on configuration

You will find detailed information on configuring the devices in the following configuration manuals:

- SCALANCE W700 nach IEEE 802.11n Web Based Management
- SCALANCE W700 nach IEEE 802.11n Command Line Interface

1.4 Service & Support

Industry Online Support

In addition to the product documentation, you are supported by the comprehensive online information platform of Siemens Industry Online Support at the following Internet address:
Link: (<https://support.industry.siemens.com/cs/de/en/>)

Apart from news, there you will also find:

- Project information: Manuals, FAQs, downloads, application examples etc.
- Contacts, Technical Forum
- The option submitting a support query:
Link: (<https://support.industry.siemens.com/cs/my?lc=en-WW>)
- Our service offer:
Right across our products and systems, we provide numerous services that support you in every phase of the life of your machine or system - from planning and implementation to commissioning, through to maintenance and modernization.

You will find contact data on the Internet at the following address:

Link: (https://www.automation.siemens.com/aspa_app/?ci=yes&lang=en)

SITRAIN - Training for Industry

The training offer includes more than 300 courses on basic topics, extended knowledge and special knowledge as well as advanced training for individual sectors - available at more than 130 locations. Courses can also be organized individually and held locally at your location.

You will find detailed information on the training curriculum and how to contact our customer consultants at the following Internet address:

Link: (<https://new.siemens.com/global/en/products/services/industry/sitrain/personal.html>)

Industrial Networks Education

Training and certification for Industrial Networks

In our Industrial Networks Education courses you'll learn to design and implement wired and wireless data networks and connect them to a corporate network. You will also receive instruction on how to secure, diagnose and optimize communication networks. Certification can also be offered to supplement almost all training courses.

Link: (<https://www.siemens.com/industrial-networks-education>)

1.5 Cybersecurity information

Siemens provides products and solutions with industrial cybersecurity functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial cybersecurity concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

For additional information on industrial cybersecurity measures that may be implemented, please visit

<https://www.siemens.com/cybersecurity-industry> (<https://www.siemens.com/industrialsecurity>).

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Cybersecurity RSS Feed under

<https://new.siemens.com/cert> (<https://www.siemens.com/cert>).

1.6 Firmware

You can find the firmware on the Internet under: (<https://support.industry.siemens.com/cs/de/en/ps/15860/dl>)

Note on firmware/software support

Check regularly for new firmware/software versions or security updates and apply them. After the release of a new version, previous versions are no longer supported and are not maintained.

Firmware

The firmware is signed and encrypted. This ensures that only firmware created by Siemens can be downloaded to the device.

Update files

You will find a SHA256 hash value in the update file. With this, you can check whether the file was downloaded unchanged. To check this, you calculate the hash value of the downloaded file and compare it with the value specified on the download page.

1.7 Open source license conditions

Note

Open source software

Read the license conditions for open source software carefully before using the product.

The license terms and copyright information can be downloaded from the WBM or CLI as a zip file.

- WBM: System > Load&Save > HTTP / TFTP / SFTP > LicenseCondition
- CLI: `sftp save filetype LicenseConditions / tftp save filetype LicenseConditions`

1.8 Error/fault

If a fault develops, send the device to your SIEMENS representative for repair. Repairs on-site are not permitted.

1.9 Decommissioning

Shut down the device properly to prevent unauthorized persons from accessing confidential data in the device memory.

To do this, restore the factory settings on the device.

Also restore the factory settings on the storage medium.

1.10 Recycling and disposal



The products are low in pollutants, can be recycled and meet the requirements of the WEEE directive 2012/19/EU for the disposal of electrical and electronic equipment.

Do not dispose of the products at public disposal sites.

For environmentally friendly recycling and the disposal of your old device contact a certified disposal company for electronic scrap or your Siemens contact (Product return (<https://support.industry.siemens.com/cs/ww/en/view/109479891>)).

Note the different national regulations.

1.11 Marken

The following and possibly other names not identified by the registered trademark sign ® are registered trademarks of Siemens AG:

SCALANCE, C-PLUG, RCoax

Safety notices

**CAUTION**

To prevent injury and damage, read the manual before using the device.

Read the safety notices

Note the following safety notices. These relate to the entire working life of the device.

You should also read the safety notices relating to handling in the individual sections, particularly in the sections "Installation" and "Connecting up".

**WARNING****Hot surfaces**

Electric devices have hot surfaces. Do not touch these surfaces. They could cause severe burns.

- Allow the device to cool down before starting any work on it.

**WARNING****EXPLOSION HAZARD**

Do not open the device when the supply voltage is turned on.

Security recommendations

3.1 Security recommendations

To prevent unauthorized access to the device and/or network, observe the following security recommendations.

General

- Check the device regularly to ensure that these recommendations and/or other internal security policies are complied with.
- Evaluate the security of your location and use a cell protection concept with suitable products (<https://www.siemens.com/industrialsecurity>).
- When the internal and external network are disconnected, an attacker cannot access internal data from the outside. Therefore operate the device only within a protected network area.
- No product liability will be accepted for operation in a non-secure infrastructure.
- Use VPN to encrypt and authenticate communication from and to the devices.
- For data transmission via a non-secure network, use an encrypted VPN tunnel (IPsec, OpenVPN).
- Separate connections correctly (WBM, SSH etc.).
- Check the user documentation of other Siemens products that are used together with the device for additional security recommendations.
- Using remote logging, ensure that the system protocols are forwarded to a central logging server. Make sure that the server is within the protected network and check the protocols regularly for potential security violations or vulnerabilities.
- Keep the firmware up to date. Check regularly for security updates of the firmware and use them.
Download (<https://sieportal.siemens.com/su/blCGg>)
Check regularly for new features on the Siemens Internet pages.

– You can find information on Industrial Security here:

Link: (<https://www.siemens.com/industrialsecurity>)

– You can find a selection of documents on the topic of network security here:

Link: (<https://support.industry.siemens.com/cs/ww/en/view/92651441>)

If Siemens detects and resolves security incidents in the products, this is published in Security Advisories. You will find the documents for the device on the Internet under: (<https://new.siemens.com/global/en/products/services/cert.html#SecurityPublications>)

WLAN

- A WLAN interface can only be used within private networks by authorized users and devices.
- No authentication or data encryption is required in an open WLAN system ("Open System Authentication"). Therefore, it cannot be used in productive operation for security reasons. Use of the "Open System" authentication type is only permissible during initial setup and for test purposes.
- We recommend that you ensure redundant coverage for WLAN clients.
- More information on data security and data encryption for SCALANCE W is available in SCALANCE W: Setup of a Wireless LAN in the Industrial Environment (<https://support.industry.siemens.com/cs/ww/en/view/22681042>)
- Authentication and encryption of WLAN with WEP (Wired Equivalent Privacy) is not considered secure and is not recommended.

Authentication and users

Note

Accessibility risk - Risk of data loss

Do not lose the passwords for the device. Access to the device can only be restored by resetting the device to factory settings which completely removes all configuration data.

- Replace the default passwords for all user accounts, access modes and applications (if applicable) before you use the device. Create a separate user account for each user that will receive access to the device.
- Define rules for the assignment of passwords. Follow current recommendations on defining strong passwords, e.g. by the German Federal Office for Information Security. Link (<https://www.bsi.bund.de>)
- Use passwords with a high password strength. Avoid weak passwords, (e.g. password1, 123456789, abcdefgh) or recurring characters (e.g. abcabc). This recommendation also applies to symmetrical passwords/keys configured on the device.
- Make sure that passwords are protected and only disclosed to authorized personnel.
- Do not use the same passwords for multiple user names and systems.
- Store the passwords in a safe location (not online) to have them available if they are lost. You can use password managers or encrypted files/drives for this purpose.
- A password must be changed if it is known or suspected to be known by unauthorized persons.

- When authentication is performed via RADIUS, make sure that all communication takes place within the security environment or is protected by a secure channel.
- Watch out for link layer protocols that do not offer their own authentication between endpoints, such as ARP or IPv4. An attacker could use vulnerabilities in these protocols to attack hosts, switches and routers connected to your layer 2 network, for example, through manipulation (poisoning) of the ARP caches of systems in the subnet and subsequent interception of the data traffic. Appropriate security measures must be taken for non-secure layer 2 protocols to prevent unauthorized access to the network. Physical access to the local network can be secured or secure, higher layer protocols can be used, among other things.

Certificates and keys

- There is a preset SSL/TLS (RSA) certificate with 4096 bit key length in the device. Replace this certificate with a user-generated, high-quality certificate with key. Use a certificate signed by a reliable external or internal certification authority. You can install the certificate in the WBM via "System > Load & Save".
- Use the certification authority including key revocation and management to sign the certificates.
- Use password-protected certificates in the format "PKCS #12".
- Make sure that user-defined private keys are protected and inaccessible to unauthorized persons.
- If there is a suspected security violation, change all certificates and keys immediately.
- Verify certificates based on the fingerprint on the server side and client side to prevent "man in the middle" attacks. Use a second, secure transmission path for this.
- Before sending the device to Siemens for repair, reset it to factory settings and replace the current certificates and keys with temporary throwaway certificates and keys that can be destroyed when the device is returned.
- The device does not perform a check for revoked certificates during certificate-based communication.

Recommended measures:

- Use certificates with a short lease time
OR
- Ensure prompt replacement of revoked certificates

For OpenVPN communication, you can use automated certificate distribution in SINEMA RC.

- For the device to be able to correctly check digital certificates and establish secure connections, the system time always needs to be up to date. Follow the steps outlined below:

Check and set time

Check whether the time is set correctly on the device, especially after a reset to factory settings or a long power supply interruption.

Enable time-of-day synchronization (recommended)

Activate one of the supported synchronization methods.

Make sure that there is a stable connection to the synchronization partner so that the device can regularly receive the current time.

3.1 Security recommendations

Physical/remote access

- Operate the devices only within a protected network area. Attackers cannot access internal data from the outside when the internal and the external network are separate from each other.
- Limit physical access to the device exclusively to trusted personnel.
The memory card or the PLUG (C-PLUG, KEY-PLUG, CLP) contains sensitive data such as certificates and keys that can be read out and modified. An attacker with control of the device's removable media could extract critical information such as certificates, keys, etc. or reprogram the media.
- Lock unused physical ports on the device. Unused ports can be used to gain forbidden access to the plant.
- We highly recommend that you keep the protection from brute force attacks (BFA) activated to prevent third parties from gaining access to the device. For more information, see the configuration manuals, section "Brute Force Prevention".
- For communication via non-secure networks, use additional devices with VPN functionality to encrypt and authenticate communication.
- When you establish a secure connection to a server (e.g. for an upgrade), make sure that strong encryption methods and protocols are configured for the server.
- Terminate the management connections (e.g. HTTP, HTTPS, SSH) properly.
- Make sure that the device has been powered down completely before you decommission it. For more information, refer to "Decommissioning (Page 8)".
- We recommend formatting a PLUG that is not being used.

Hardware / Software

- Use VLANs whenever possible as protection against denial-of-service (DoS) attacks and unauthorized access.
- Restrict access to the device by setting firewall rules or rules in an access control list (ACL).
- Selected services are enabled by default in the firmware. It is recommended to enable only the services that are absolutely necessary for your installation.
For more information on available services, see "List of available services (Page 18)".
- To ensure you are using the most secure encryption methods available, use the latest web browser version compatible with the product. Also, the latest web browser versions of Mozilla Firefox, Google Chrome, and Microsoft Edge have 1/n-1 record splitting enabled, which reduces the risk of attacks such as SSL/TLS Protocol Initialization Vector Implementation Information Disclosure Vulnerability (for example, BEAST).
- Ensure that the latest firmware version is installed, including all security-related patches. You can find the latest information on security patches for Siemens products at the Industrial Security (<https://www.siemens.com/industrialsecurity>) or ProductCERT Security Advisories (<https://www.siemens.com/cert>) website.
For updates on Siemens product security advisories, subscribe to the RSS feed on the ProductCERT Security Advisories website or follow @ProductCert on Twitter.

- Enable only those services that are used on the device, including physical ports. Free physical ports can potentially be used to gain access to the network behind the device.
- Use the authentication and encryption mechanisms of SNMPv3 if possible. Use strong passwords.
When using SNMP (Simple Network Management Protocol):
 - Configure SNMP to generate a notification when authentication errors occur. For more information, see WBM "System > SNMP > Notifications".
 - Ensure that the default community strings are changed to unique values.
 - Use SNMPv3 whenever possible. SNMPv1 and SNMPv2c are considered non-secure and should only be used when absolutely necessary.
 - If possible, prevent write access.
- Files (e.g. configuration files) can be downloaded from the device. Ensure that the files are adequately protected. The options for achieving this include storing the files in a secure location and transmitting them only through secure communication channels. In addition, you can create hash sums from the files after the download. This allows you to check that the file is unchanged before further use.
- Configuration files can be password-protected during download. You enter passwords on the WBM page "System > Load & Save > Passwords".
- The names of the configuration files can be changed. To improve security, do not use spaces in the TFTP file name.
- Use the security functions such as address translation with NAT (Network Address Translation) or NAPT (Network Address Port Translation) to protect receiving ports from access by third parties.
- Use WPA2/ WPA2-PSK with AES to protect the WLAN. You can find additional information in the configuration manual Web Based Management "Security menu".

Secure/ non-secure protocols

- Use secure protocols if access to the device is not prevented by physical protection measures.
- Disable or restrict the use of non-secure protocols. While some protocols are secure (e.g. HTTPS, SSH, 802.1X, etc.), others were not designed for the purpose of securing applications (e.g. SNMPv1/v2c, etc.).
Therefore, take appropriate security measures against non-secure protocols to prevent unauthorized access to the device/network. Use non-secure protocols on the device using a secure connection (e.g. SINEMA RC).
- If non-secure protocols and services are required, ensure that the device is operated in a protected network area.

3.1 Security recommendations

- The following protocols and services can only be used in physically separate networks:
 - Non-authenticated and unencrypted ports
 - DCP
 - DHCP
 - DNS client
 - HTTP
 - IEEE 802.1x (RADIUS)
 - iPRP
 - iPCF
 - iPCF-MC
 - LLDP
 - NTP client
 - ICMP
 - PROFINET
 - Remote Packet Capture
 - SIMATIC NET Time
 - SMTP client
 - SNMP v1/2c
 - SNMP traps
 - SNTTP client
 - STP, RSTP and MSTP
 - Syslog client
 - TCP event
 - Telnet
 - TFTP

- The following protocols provide secure alternatives:
 - SNMPv1/v2c → SNMPv3
Check whether use of SNMPv1/v2c is necessary. SNMPv1/v2c is classified as non-secure. Use the option of preventing write access. The product provides you with suitable setting options.
If SNMP is enabled, change the community names. If no unrestricted access is necessary, restrict access with SNMP.
Use SNMPv3 in conjunction with passwords.
 - HTTP → HTTPS
 - Telnet → SSH
 - NTP → NTPsecure
 - TFTP → SFTP
 - Syslog Client → Syslog Client TLS
- Use secure protocols when access to the device is not secured by physical protection measures.
- If you require non-secure protocols and services, operate them only within a protected network area.
- Select a trusted DNS provider.
- Restrict the services and protocols available to the outside to a minimum.
- With authentication on the RADIUS server and RADIUS client, use the Message Authenticator attribute to check packets.
- If you use RADIUS for management access to the device, enable secure protocols and services.
- The LAN interface of the product must not be operated in unprotected or untrusted networks (e.g. the Internet) without additional upstream protective devices.
- Only operate Syslog, SNTP and other non-secure protocols over secure connections (e.g. SINEMA RC/OpenVPN).

3.2 Available interfaces

The following is a list of all available interfaces through which the device can be accessed.

Interface	Default status	Change to the status	
		WBM / CLI (administrator)	Physical
LAN	Enabled	✓	-
WLAN	Disabled	✓	-
Digital input ¹⁾	Disabled	-	✓

3.3 Available services

Interface	Default status	Change to the status	
		WBM / CLI (administrator)	Physical
Digital output ¹⁾	Disabled	✓	✓
PLUG slot ²⁾	Enabled	✓	✓

1) Only with SCALANCE W788/W748

2) Not with SCALANCE W760/W720

3.3 Available services

List of available services

The following is a list of all available services and their ports through which the device can be accessed.

The table includes the following columns:

- **Service**
The services that the device supports
- **Default port status**
This is the status of the port in the delivery state (factory setting).
- **Configurable port/service**
Indicates whether the port number or the service can be configured via WBM / CLI.
- **Authentication**
Specifies whether the communication partner is authenticated.
If optional, the authentication can be configured as required.
- **Encryption**
Specifies whether the transfer is encrypted.
If optional, the encryption can be configured as required.

Service	Protocol / Port number	Default port status	Configurable		Authentication	Encryption ¹⁾
			Port	Service		
DHCP Client IPv4	UDP/68	Disabled Only outgoing	--	✓	--	--
DHCP Client IPv6	UDP/546	Disabled Only outgoing	--	✓	--	--
DHCP Server	UDP/67	Closed	--	✓	--	--
DNS Client	TCP/53 UDP/53	Active Only outgoing	--	✓	--	--
EthernetIP	TCP/44818 UDP/2222 UDP/44818	Closed	--	✓	--	--
HTTP	TCP/80	Disabled ⁴⁾	✓	✓	✓	--
HTTPS	TCP/443	Active	✓	✓	✓	✓

Service	Protocol / Port number	Default port status	Configurable		Authentication	Encryption ¹⁾
			Port	Service		
NTP Client	UDP/123	Disabled Only outgoing	✓	✓	-	-
NTP Client (secure)	UDP/123	Disabled Only outgoing	✓	✓	✓	-
Packet Capture	TCP/2002 TCP/2003 ²⁾	Disabled	-	✓	-	-
Ping	ICMP	Active	-	-	-	-
PROFINET	UDP/34964 UDP/49154 UDP/49155	Disabled	-	✓	-	-
RADIUS Client	UDP/1812	Disabled Only outgoing	✓	✓	✓	-
SFTP Client	TCP/22	Active Only outgoing	✓	✓	✓	✓
SMTP Client	TCP/25	Disabled Only outgoing	✓	✓	-	-
SMTP Client (secure)	TCP/465	Disabled Only outgoing	✓	✓	Optional	✓
SNMPv1/v2c ³⁾	UDP/161	Disabled	✓	✓	-	-
SNMPv3	UDP/161	Disabled	✓	✓	Optional	Optional
SNMP Traps	UDP/162	Disabled Only outgoing	-	✓	-	-
SNTP Client	UDP/123	Disabled Only outgoing	✓	✓	-	-
SSH	TCP/22	Active	✓	✓	✓	✓
Syslog Client	UDP/514	Disabled Only outgoing	✓	✓	-	-
Syslog Client TLS	TCP/6514	Disabled Only outgoing	✓	✓	-	✓
Telnet	TCP/23	Disabled	✓	✓	✓	-
TFTP Client	UDP/69	Disabled Only outgoing	✓	✓	-	-

¹⁾ You can find additional information on the encryption methods used in the WBM appendix "Ciphers used".

²⁾ The basic port of Packet Capture for the communication to Wireshark is TCP/2002. For each enabled interface, another port is enabled. Each additional port is an increment of TCP/2002, i.e. TCP/2003, TCP/2004, TCP/2005 etc.

³⁾ Read Only

⁴⁾ The HTTP port is always open. If the service is disabled, automatic HTTP forwarding to the HTTPS port takes place.

The following is a list of all available Layer 2 services through which the device can be accessed.

3.3 Available services

The table includes the following columns:

- **Layer 2 service**
The Layer 2 services that the device supports.
- **Default status**
The default status of the service (open or closed).
- **Service configurable**
Indicates whether the service can be configured via WBM / CLI.


Layer 2 service	Default setting of service	Service configurable	Encryption
DCP	Active	✓	-
ICMP	Active	-	-
iPCF	Disabled	✓	-
iPCF-MC	Disabled	✓	-
iPRP	Disabled	✓	-
LLDP	Active	✓	-
MSTP	Disabled	✓	-
RSTP	Disabled	✓	-
SIMATIC NET TIME	Disabled	✓	-
802.1n	Disabled	✓	Optional

Description of the device


4.1 Structure of the type designation

Structure of the type designation

The type designation of the device is made up of several parts that have the following meaning:



4.2 Device view



4.3 Components of the product

The following components are supplied with the product:

- One SCALANCE W device
- Three protective caps for the M12 sockets:
 - 2 x Ethernet
 - 1 x power supply

- Two protective caps for the antenna sockets
- One product DVD

Note

The mounting adapter and the bracket for installation on a DIN rail do not ship with the product, see Accessories (Page 23).

Please check that the consignment you have received is complete. If the consignment is incomplete, contact your supplier or your local Siemens office.

4.4 Accessories

Note on accessories

Technical data subject to change.

You will find further information on the range of accessories in the Industry Mall (<https://mall.industry.siemens.com>)

Use the TIA Selection Tool (<https://mall.industry.siemens.com/tst/>) for configuring the device.

4.4.1 Installation

Component	Description	Article number
Mounting adapter standard mounting rail	Adapter for mounting the SCALANCE W778/W38 on a 35 mm DIN rail according to DIN EN 50 022	6GK5798-8MF00-0AA1
Bracket support	Bracket support for 90° mounting	6GK5798-8MA00-0AA1

4.4.2 PLUG

Component	Description	Article number
C-PLUG	Configuration PLUG	
	Exchangeable storage medium for configuration data. 256 MB	6GK1900-0AB10
KEY-PLUG features	Enabling of iFeatures and exchangeable storage medium for storage of configuration data	
	KEY-PLUG W780 iFeatures AP	6GK5907-8PA00
	KEY-PLUG W740 iFeatures Client	6GK5907-4PA00
KEY-PLUG W700 Security	W700 Security Enabling of "Inter AP Blocking" and exchangeable storage medium for storage of configuration data	6GK5907-0PA00

4.4.3 Industrial Ethernet

M12 data plug-in connector

Component	Description		Article number
IE FC M12 PLUG PRO 2x2	M12 data plug-in connector for IE FC TP cables 2x2, IP65/67, D-coded, axial cable outlet	1 connector per pack- age	6GK1901-0DB20-6 AA0
		8 connectors per pack- age	6GK1901-0DB20-6 AA8

Cables Industrial Ethernet

Component	Description	Article number
IE FC TP STANDARD CABLE GP2X2 (PROFINET type A)	Standard bus cable, TP installation cable for connec- tion to FC OUTLET RJ-45, for universal use, 4-wire, shielded, CAT 5E Sold by the meter	6XV1840-2AH10
IE FC TP ROBUST STANDARD CABLE GP 2X2 (PROFINET type A)	Standard bus cable, ATPE outer jacket for connection to FC RJ-45 PLUG and FC OUTLET RJ-45, fixed instal- lation, for universal use, 4-wire, shielded, CAT 5 Sold by the meter	6XV1841-2A
IE FC TP ROBUST FLEXIBLE CABLE GP 2X2 (PROFINET type B)	Flexible bus cable, TPE outer jacket for connection to FC RJ-45 PLUG and FC OUTLET RJ-45, flexible wires, 4-wire, shielded, CAT 5 Sold by the meter	6XV1841-2B
IE FC TP FLEXIBLE CABLE GP 2X2 (PROFINET type B)	Flexible bus cable, TP installation cable, flexible wires, shielded, CAT 5 Sold by the meter	6XV1870-2B
IE FC TP TRAILING CABLE 2X2 (PROFINET type C)	Highly flexible bus cable, TP installation cable for connection to FC OUTLET RJ-45, for use in drag chains, 4-wire, shielded, CAT 5 Sold by the meter	6XV1840-3AH10
IE TP TORSION CABLE 2X2 (PROFINET type C)	Highly flexible bus cable, TP installation cable for use in highly flexible applications (torsion), 4-wire Sold by the meter	6XV1870-2F
IE CONNECTING CABLE M12-180/IE RJ45	Flexible IE connecting cable, 4-wire, preassembled with a 4-pin M12 plug (D-coded) and an IE FC RJ-45 plug 145	6XV1871-5T*
IE CONNECTING CABLE M12-180/M12-180	Flexible IE connecting cable, 4-wire, preassembled with two 4-pin M12 plugs (D-coded)	6XV1870-8A*

* Available in different lengths

4.4.4 Power supply

Energy cable

Component	Description	Article number
Energy cable 2 x 0.75	Energy cable for connection of signaling contact and power supply 24 VDC, stranded wire 2 x 0.75 mm ² , trailing type, not assembled Sold by the meter	6XV1812-8A
Robust Energy Cable 4 x 0.75	Energy cable for connection of power supply 24 VDC, 4-wire stranded 4 x 0.75 mm ² , robust, flexible, not assembled Sold by the meter	6XV1801-2A
M12 PLUG-IN CABLE	Flexible plug-in power cable to connect the power supply 24 VDC, 4-wire, preassembled with a 4-pin M12 plug and an M12 socket (A-coded)	6XV1801-5D*

* Available in different lengths

Socket

Component	Description	Article number
IE POWER M12 CABLE CONNECTOR PRO	Socket for the 24 VDC power supply. 4-pin, A-coded pack of 3	6GK1907-0DC10-6AA3

4.4.5 Flexible connecting cables, antennas and accessories

You will find an overview of the IWLAN products and their accessories in the Order overview (<https://support.industry.siemens.com/cs/ww/en/view/109766333>).

4.4.5.1 Flexible connecting cables

Flexible connecting cable N-Connect/R-SMA

Flexible connecting cable for connecting an antenna to a SCALANCE W device with R-SMA connectors, preassembled with an N-Connect male and an R-SMA male connector:

Length	Article number
0.3 m	6XV1875-5CE30
1 m	6XV1875-5CH10
2 m	6XV1875-5CH20
5 m	6XV1875-5CH50
10 m	6XV1875-5CN10

4.4 Accessories

For railway applications, the following connecting cable are available:

Length	Article number
1 m	6XV1875-5TH10
2 m	6XV1875-5TH20
5 m	6XV1875-5TH50

Flexible connecting cable N-Connect/N-Connect

Flexible connecting cable for connecting an antenna to a SCALANCE W device with N-Connect connectors, preassembled with two N-male connectors:

Length	Article number
1 m	6XV1875-5AH10
2 m	6XV1875-5AH20
5 m	6XV1875-5AH50
10 m	6XV1875-5AN10

For railway applications, the following connecting cable are available:

Length	Article number
1 m	6XV1875-5SH10
2 m	6XV1875-5SH20
5 m	6XV1875-5SH50

Flexible connecting cable IWLAN QMA/N-Connect male/female

Adapter cable for connecting a MIMO antenna with QMA connectors to the flexible connecting cables; preassembled with one QMA male and one N-Connect female connector; scope of delivery 3 units:

Length	Article number
1 m	6XV1875-5JH10

For railway applications, the following connecting cable is available, scope of delivery 1 unit:

Length	Article number
1 m	6XV1875-5VH10

4.4.5.2 Lightning protection

Note

Lightning protection elements can be used as bushings.

Component	Description	Article number
LP798-1N	Lighting protector with N/N female/female connector with gas discharge technology	6GK5798-2LP00-2AA6
LP798-2N	Lighting protector with N/N female/female connector with quarter wave technology	6GK5798-2LP10-2AA6

4.4.5.3 Terminating resistor

Component	Description	Article number
TI795-1N	Electrical connector N-Connect, male Pack of 1	6GK5795-1TN00-1AA0

4.4.5.4 Cabinet feedthrough

Component	Description	Article number
IE M12 Panel Feed-through	Cabinet feedthrough for conversion from M12 connector technology (D-coded, IP65) to RJ-45 connector technology (IP20) pack of 5	6GK1901-ODM20-2AA5
IE M12 Panel Feed-through PRO	Cabinet feedthrough for conversion from M12 connector technology (D-coded, IP65) to M12 connector technology (D-coded, IP65) pack of 5	6GK1901-ODM30-2AA5
IE M12 Panel Feed-through 4X2	Cabinet feedthrough for conversion from M12 connector technology (X-coded, IP65/67) to RJ-45 connector technology (X-coded, IP20) pack of 5	6GK1901-ODM40-2AA5
N-Connect/N-Connect female/ female Panel Feed-through	Panel feedthrough for wall thicknesses up to a maximum of 4.5 mm, two N-Connect female connectors.	6GK5798-2PP00-2AA6
N-Connect/SMA-Connect female/ female Panel Feed-through	Panel feedthrough for wall thicknesses up to a maximum of 5.5 mm, two N-Connect/SMA female connectors.	6GK5798-0PT00-2AA6

4.4.5.5 Antennas

Note

When you select an antenna, keep in mind the national approvals for your device.

You will find more detailed information in Link (<http://www.siemens.com/wireless-approvals>).

4.4 Accessories

Type	Properties	Article number
IWLAN RCoax ANT792-4DN	RCoax helical antenna with circular polarization for RCoax systems, 4 Bi, 2.4 GHz, IP65, N-Connector female.	6GK5792-4DN00-0AA6
ANT792-6MN	Omnidirectional antenna, mast/wall mounting, 6 dBi 2.4 GHz, IP67, N-Connect female	6GK5792-6MN00-0AA6
ANT792-8DN	Directional antenna, mast/wall mounting, 14 dBi 2.4 GHz, IP32, N-Connect female	6GK5792-8DN00-0AA6
ANT793-6DG	Wide angle antenna, mast/wall mounting, 9 dBi 5 GHz, IP66/67, 2 x N-Connect female	6GK5793-6DG00-0AA0
ANT793-8DJ	Directional antenna, mast/wall mounting, 18 dBi 5 GHz, IP67, 2 x N-Connect female	6GK5793-8DJ00-0AA0
ANT793-8DK	Directional antenna, mast/wall mounting, 23 dBi 5 GHz, 2 x N-Connect female	6GK5793-8DK00-0AA0
ANT793-8DL	Directional antenna vertical-horizontal polarized, 5 GHz, 14dBi, IP66, 2 x N-Connector female	6GK5793-8DL00-0AA0
ANT793-8DP	Directional antenna, mast/wall mounting, 13 / 13.5 dBi 4.9 GHz and 5 GHz, N-Connect female This antenna is not available in Korea	6GK5793-8DP00-0AA0
IWLAN RCoax ANT793-4MN	RCoax $\lambda/4$ antenna with vertical polarization for RCoax systems, 6 dBi, 5 GHz, IP65, N-Connector female	6GK5793-4MN00-0AA6
ANT795-4MA	Omnidirectional antenna, directly on the device, 3/5 dBi 2.4 GHz and 5 GHz, IP30, R-SMA connector male for direct installation on the device, angle connector adjustable 0° - 180°.	6GK5795-4MA00-0AA3
ANT795-4MB	Omnidirectional antenna, 2/3 dBi 2.4 GHz and 5 GHz, IP30, R-SMA connector female for direct mounting on the device, angle connector adjustable 0° to 90°	6GK5795-4MB00-0Ax0
ANT795-4MC	Omnidirectional antenna, 3/5 dBi, 2.4 GHz and 5 GHz, IP65, N-Connect male for direct installation on the device, straight connector.	6GK5795-4MC00-0AA3
ANT795-4MD	Omnidirectional antenna, 3/5 dBi, 2.4 GHz and 5 GHz, IP65, N-Connect male for direct installation on the device, 90° connector.	6GK5795-4MD00-0AA3
ANT795-4MX	Omnidirectional antenna, 2/2.5 dBi, 2.4 GHz and 5 GHz, IP69K, N-Connector male	6GK5795-4MX00-0AA0
ANT795-6DC	Wide angle antenna, mast/wall mounting, 9 dBi 2.4 GHz and 5 GHz, N-Connect female	6GK5795-6DC00-0AA0
ANT795-6MN	Omnidirectional antenna, mounted on roof/vehicle, 6/8 dBi 2.4 GHz and 5 GHz, N-Connect female	6GK5795-6MN10-0AA6
ANT795-6MT	Omnidirectional antenna (MIMO), mounted on roof/vehicle/ceiling, 5/7 dBi 2.4 GHz and 5 GHz, 3 x QMA connector female	6GK5795-6MT00-0AA0
ANT795-6MP	Omnidirectional antenna, 5/7 dBi, 2.4 GHz and 5 GHz, IP65/67, N-Connector female	6GK5795-6MP00-0AA0

Type	Properties	Article number
IWLAN RCoax Cable 2,4 GHz PE 1/2"	Omnidirectional antenna, 0 Bi 2.400 -2.485 GHz, N-Connect female	6XV1875-2A
IWLAN RCoax Cable 5 GHz PE 1/2"	Omnidirectional antenna, 0 Bi 5.150 -5.875 GHz, N-Connect female	6XV1875-2D

NOTICE**ANT795-4MA**

The ANT795-4MA antenna has degree of protection IP30 and is therefore only suitable for dry environments.

Note**ANT793-8DJ**

The antenna ANT793-8DJ may only be used with the flexible connecting cable 6XV1875-5CH50 (5 m length) or 6XV1875-5CN10 (10 m length). Other flexible connecting cables are not permitted.

Notice for USA/Canada

Only one antenna per device can be used (connected to R1A1, R1A2 or R2A1, R2A2).

Note**ANT793-8DK**

The antenna ANT793-8DK may only be used with the flexible connecting cable 6XV1875-5CN10 (10 m length). Other flexible connecting cables are not permitted.


Notice for USA/Canada

Only one antenna per device can be used (connected to R1A1, R1A2 or R2A1, R2A2).

4.5 LED display

Information on operating status and data transfer

On the front of the housing, several LEDs provide information on the operating status of the device:



LED	Color	Meaning
L1	Off 	Power supply L1 too low.
	Green 	Power supply L1 is applied.
L2	Off 	Power supply L2 too low.
	Green 	Power supply L2 is applied.
PoE	Off 	The device is not supplied using PoE.
	Green 	The device is supplied using PoE.

LED	Color	Meaning
P1	Off 	There is no connection over the Ethernet port P1.
	Green 	There is a connection over the Ethernet port P1 (link).
	Flashing green and yellow 	Data transfer over the Ethernet interface P1.
P2	Off 	There is no connection over the Ethernet port P2.
	Green 	There is a connection over the Ethernet port P2 (link).
	Flashing green and yellow 	Data transfer over the Ethernet interface P2.

4.5 LED display

LED	Color	Meaning
R1	Off 	The WLAN interface 1 is deactivated.
	Green 	<i>Access point mode:</i> The WLAN interface 1 is initialized and ready for operation. <i>Client mode:</i> There is a connection over the WLAN interface 1.
	Flashing green and yellow 	Data transfer via the WLAN interface 1.
	Flashing yellow 	<i>Client mode:</i> The client is searching for a connection to an access point.
	Flashing yellow  Interval: 100 ms on / 100 ms off	<i>Access point mode:</i> With DFS (802.11h), the channel is scanned for one minute for competing radar signals before the channel can be used for data traffic. <i>Client mode:</i> The client waits for the MAC address due to the setting "Automatic" for the "MAC mode" parameter and is not connected to an access point.
	Flashing yellow and green  Interval: 3x (100 ms on / 100 ms off) 1x 1000 ms on	<i>Client mode:</i> The client waits for the MAC address due to the setting "Automatic" for the "MAC mode" parameter and is connected to an access point.

LED	Color	Meaning
F	Off 	No fault/error.
	Red 	The device is starting up or an error has occurred.
	Flashing red  Interval: 500 ms on / 500 ms off	The bootloader waits in this state for a new firmware file that you can download by TFTP.
	Flashing red  Interval: 1 s on/ 1 s off	The device is starting up for the first time or has been reset to factory settings.
	Flashing red  Interval: 2000 ms on / 200 ms off	Firmware on PLUG: The device is performing a firmware update or downgrade.
	Red  Simultaneous R1 yellow flashing 	A competing radar signal was found on all enabled channels.
P1 P2 R1	Flashing yellow 	The port LEDs flash for detection of device location. The "LED flash" function is • Either with SINEC PNI • Or via the WBM page "Discovery and Set via DCP"

4.6 Reset button

Note

Primary user (radar) on all enabled channels (only when DFS is enabled)

If the device detects competing radar signals on all enabled channels of the WLAN interface, the **F** LED is lit and **R1** flash. No data traffic is then possible for the next 30 minutes. After this time, the device runs the scan again and checks whether a primary user still exists. If no primary user is detected, data traffic is possible again.


The wait time of 30 minutes is necessary due to legal requirements and cannot be shortened even by restarting the device.

4.6 Reset button

Position

NOTICE
Loss of the degree of protection
If the cover is not mounted correctly, the device is not water and dust proof.

The Reset button is located on the top of the device under the cover ①.



Note

The Reset button is a long-stroke button with a pressure point.

Press the button until you feel the pressure point.

Functions of the reset button

The reset button has the following functions:

- **Restart of the device**
To restart the device, press the Reset button briefly.

Note

If you make changes to the configuration and restart immediately afterwards with the reset button, the changes may be lost. If you restart the device using the WBM (menu command "System > Restart") or using the CLI (command "restart" in the Privileged EXEC Modus), the configuration changes are always retained.

- **Loading new firmware**
If the "Load & Save" menu command of Web Based Management is unsuccessful, the reset button can be used to load new firmware. This situation can occur if there is a power outage during the normal firmware update. You will find further information in the configuration manual in Downloading new firmware using TFTP without WBM and CLI (Page 66).
- **Resetting the device to the factory defaults**
The device can be reset to the factory defaults during operation. You will find more detailed information in the configuration manual in Resetting the device to factory defaults (Page 65).

NOTICE
Previous settings
If you reset, all the changes you have made will be overwritten by factory defaults.

NOTICE
Inadvertent reset
An inadvertent reset can cause disturbances and failures in the configured network with further consequences.

4.7 PLUG

The PLUG is available in the following variants:

- C-PLUG: The removable data storage medium only saves the configuration data of the device.
- KEY-PLUG: In addition to the configuration data, the removable data storage medium contains a license with which special functions are enabled, e.g. iFeatures.

You will find the article numbers under Accessories (Page 23).

NOTICE

Do not remove or insert a C-PLUG / KEY-PLUG during operation!

A PLUG may only be removed or inserted when the device is turned off.

The device checks whether or not a PLUG is inserted at one second intervals. If it is detected that the PLUG was removed, there is a restart.

If a KEY-PLUG was inserted in the device, the device changes to a defined error state following the restart. With SCALANCE W, the available wireless interfaces are deactivated in this case.

If the device was configured at some time with a PLUG, the device can no longer be used without this PLUG. To be able to use the device again, reset the device to the factory settings.

NOTICE

Loss of the degree of protection

When the cover is not mounted correctly, the device loses its degree of protection.

Position

The PLUG slot is on the top of the device housing under a cover, see Device description (Page 22).

Function

The device supports the following modes of operation:

- **Without PLUG**
The device saves the configuration data in the internal memory. This mode is active when no PLUG is inserted.
- **With PLUG**
If an unwritten PLUG (factory status or deleted with Clean function) is used, the local configuration already existing on the device is automatically stored on the inserted PLUG. If the PLUG contains a license, additional functions are also enabled.
A device with a written and accepted PLUG ("ACCEPTED" status) uses the configuration data of the PLUG automatically when it starts up. Acceptance is possible only when the data was written by a compatible device type.
One exception to this can be the IP configuration if it is set using DHCP and the DHCP server has not been reconfigured accordingly. Reconfiguration is necessary if you use functions based on MAC addresses.
The configuration stored on the PLUG is displayed over the user interfaces.
If changes are made to the configuration, the device stores the configuration directly on the PLUG, if this is in the "ACCEPTED" status. The internal memory is neither read nor written.

Response to errors

Inserting a PLUG that does not contain the configuration of a compatible device type, accidentally removing the PLUG/KEY-PLUG or general malfunctions of the PLUG are signaled by the diagnostics mechanisms of the device (LEDs, Web-Based Management (WBM), SNMP,

4.7 PLUG

Command Line Interface (CLI) and PROFINET diagnostics). The user then has the choice of either removing the PLUG again or selecting the option to reformat the PLUG.

Note

Incompatibility with previous versions with PLUG inserted

During the installation of a previous version of the firmware, the configuration data can be lost. In this case, the device starts up with the factory settings after the firmware has been installed. In this situation, if a PLUG is inserted in the device, following the restart, this has the status "NOT ACCEPTED" since the PLUG still has the configuration data of the previous more up-to-date firmware. This allows you to return to the previous, more up-to-date firmware without any loss of configuration data. If the original configuration on the PLUG is no longer required, the PLUG can be deleted or rewritten manually using "System > PLUG".

Installation and removal

5.1 Safety notices for installation

Safety notices

When installing the device, keep to the safety notices listed below.

NOTICE
Improper mounting Improper mounting may damage the device or impair its operation. • Before mounting the device, always ensure that there is no visible damage to the device. • Mount the device using suitable tools. Observe the information in the respective section about mounting.

 WARNING
Improper disassembly Improper disassembly may result in a risk of explosion in hazardous areas. For proper disassembly, observe the following: • Before starting work, ensure that the electricity is switched off. • Secure remaining connections so that no damage can occur as a result of disassembly if the system is accidentally started up.

 CAUTION
Danger of injury by falling objects If the SCALANCE W7x8 is subjected to strong vibration (> 10 g), mounting on a 35 mm DIN rail does not provide adequate support. Under such conditions, the device can come out of the mounting and may cause injury. In this case, install the device on an S7-300 standard rail or on a wall.

 CAUTION
Minimum distance to antennas Fit the device so that there is a minimum clearance of 20 cm between antennas and persons.

5.1 Safety notices for installation

 WARNING

If a device is operated in an ambient temperature of more than 50 °C, the temperature of the device housing may be higher than 70 °C. The device must therefore be installed so that it is only accessible to service personnel or users that are aware of the reason for restricted access and the required safety measures at an ambient temperature higher than 50 °C.

 WARNING

If the device is installed in a cabinet, the inner temperature of the cabinet corresponds to the ambient temperature of the device.

 WARNING

The device is intended for indoor use only.

Safety notices on use in hazardous areas

General safety notices relating to protection against explosion

 WARNING

When used in hazardous environments corresponding to Class I, Division 2 or Class I, Zone 2, the device must be installed in a cabinet or a suitable enclosure.

 WARNING

EXPLOSION HAZARD

Replacing components may impair suitability for Class 1, Division 2 or Zone 2.

 WARNING

The device shall only be used in an area with pollution degree 1 or 2 (according to EN/ IEC 60664-1, GB/T 16935.1).

Notes for use in hazardous locations according to ATEX, IECEx, UKEX and CCC Ex

If you use the device under ATEX, IECEx, UKEX or CCC Ex conditions you must also keep to the following safety instructions in addition to the general safety instructions for protection against explosion:

 WARNING

To comply with EU Directive 2014/34 EU (ATEX 114), UK Regulation SI 2016/1107 or the conditions of IECEx or CCC-Ex, the housing or cabinet must meet the requirements of at least IP54 (according to EN/IEC 60529, GB/T 4208) in compliance with EN IEC/IEC 60079-7, GB/T 3836.3.

Safety notices when using according to FM

If you use the device under FM conditions you must also keep to the following safety notices in addition to the general safety notices for protection against explosion:

 WARNING

EXPLOSION HAZARD

The equipment is intended to be installed within an enclosure/control cabinet. The inner service temperature of the enclosure/control cabinet corresponds to the ambient temperature of the module. Use installation wiring connections with admitted maximum operating temperature of at least 10 °C higher than maximum ambient temperature.

 WARNING

Wall mounting is only permitted if the requirements for the housing, the installation regulations, the clearance and separating regulations for the control cabinets or housings are adhered to. The control cabinet cover or housing must be secured so that it can only be opened with a tool. An appropriate strain-relief assembly for the cable must be used.

 WARNING

Wall mounting outside of the control cabinet or housing does not fulfill the requirements of the FM approval.

Note

You must not install the device on a wall in hazardous areas.

5.2 Types of installation

For the device, you have the following options:

- Wall mounting
- Installation on a DIN rail
 - With a DIN rail mounting adapter
 - With a bracket support and the DIN rail mounting adapter for space saving 90° mounting, see Accessories (Page 23)

Note

Installation pointing upwards when using the device according to UL

Installation pointing upwards (e.g. desktop operation) is not permitted for this device.

Note

The device is only approved for operation in closed rooms. Pay attention to the ambient and environmental conditions (Page 69).

Antennas, in particular directional antennas, must be mounted in keeping with their characteristics (refer to the technical specifications of the antenna under Radiation pattern diagrams).

5.3 Wall mounting

Note

Depending on the mounting surface, use suitable fittings.

Note

The wall mounting must be capable of supporting at least four times the weight of the device.

To mount the device on a wall, follow the steps below:

1. Prepare the drill holes for wall mounting. For the precise dimensions, refer to the section "Dimension drawing (Page 73)".
2. Secure the device to the wall with four screws. The screws are not supplied with the device.
3. Connect the power supply, refer to the section "Power supply (Page 53)".
4. Fit the antennas, refer to the section "Antennas (Page 56)".


5.4 Installation on a DIN rail

5.4.1 Installation with the DIN rail mounting adapter

The DIN rail mounting adapter is not included with the product, see Accessories (Page 23).


Assembly

1. Screw the DIN rail mounting adapter **1** to the rear of the device. The mounting material is supplied with the DIN rail mounting adapter.



2. Place the device on the upper edge of the DIN rail **2**.

3. Press the device against the DIN rail ❸ until the DIN rail slider catch locks in place.




4. Connect the power supply, refer to the section "Power supply (Page 53)".
5. Fit the antennas, refer to the section "Antennas (Page 56)".

Uninstalling

1. Turn off the power to the device.
2. Disconnect all connected cables.
3. Pull the DIN rail slider down with a screwdriver ❶.

4. Tilt the device forward ② and remove the device from the DIN rail.



5. Loosen the screws of the DIN rail mounting adapter completely.


5.4.2 Mounting with bracket support

With the bracket support the device can be mounted on a DIN rail rotated through 90°


The DIN rail mounting adapter and bracket holder are not included with the product, see Accessories (Page 23).

Installation

1. Screw (M3, tightening torque 0.7 Nm) the bracket holder **1** to the DIN rail mounting adapter **2**. The mounting material ships with the product.




2. Screw (tightening torque 0.7 Nm) the bracket holder **3** to the side of the device.



3. Place the device on the upper edge of the DIN rail **4**.

4. Press the device **5** against the DIN rail until the DIN rail slider catch locks in place.




5. Connect the power supply, refer to the section "Power supply (Page 53)".
6. Fit the antennas, refer to the section "Antennas (Page 56)".

Uninstalling

1. Turn off the power to the device.
2. Disconnect all connected cables.
3. Pull the DIN rail slider down with a screwdriver **1**.

4. Tilt the device forward **2** and remove the device from the DIN rail.



5. Loosen the screws completely.

Connection

6.1 Safety when connecting up

Safety notices

When connecting up the device, keep to the safety notices listed below.

Note

Strain relief for the Ethernet cables

In order to avoid mechanical stress on the Ethernet cables and resulting interruption of the contact, fasten the cables at a short distance from the connector using a cable guide or busbar.

Note

Close unused sockets

Close all unused M12 sockets with protective caps (tightening torque at least 0.4 Nm) to achieve the specified type of protection.

Lightning protection



! WARNING

Danger due to lightning strikes

Antennas installed outdoors must be within the area covered by a lightning protection system. Make sure that all conducting systems entering from outdoors can be protected by a lightning protection potential equalization system.

When implementing your lightning protection concept, make sure you adhere to the VDE 0182 or IEC 62305 standard.

Suitable lightning protectors are available in the accessories (Page 26) of SIMATIC NET Industrial WLAN.

Note

We recommend that you use the maintenance-free lightning protector LP798-2N.

Exception: When there is also DC power supplied via the antenna cable. In this case, only the lightning protector LP798-1N can be used.

6.1 Safety when connecting up



WARNING

Danger due to lightning strikes

Installing this lightning protector between an antenna and a SCALANCE W device is not adequate protection against a lightning strike. The LP798-1N lightening protector only works within the framework of a comprehensive lightning protection concept. If you have questions, ask a qualified specialist company.

Note

The requirements of EN61000-4-5, surge immunity tests on power supply lines, are met only when a Blitzductor is used with 24 VDC:

BVT AVD 24

article number: 918 422

Manufacturer: DEHN+SÖHNE GmbH+Co.KG, Hans Dehn Str. 1, Postfach 1640, D - 92306 Neumarkt, Germany

Supply voltage

WARNING

Power supply

The device is designed for operation with a directly connectable safety extra low voltage (SELV) from a limited power source (LPS).

The power supply therefore needs to meet at least one of the following conditions:

- Only safety extra low voltage (SELV) with limited power source (LPS) complying with IEC 62368-1 / EN 62368-1 / VDE 62368-1 may be connected to the power supply terminals.
- The power supply unit for the device must meet NEC Class 2 according to the National Electrical Code (r) (ANSI / NFPA 70).

If the equipment is connected to a redundant power supply (two separate power supplies), both must meet these requirements.

Grounding



WARNING

Danger to life from overvoltage, fire hazard

When using outdoor antennas, the shared or grounded pin of the circuit must be connected to the shield of the coaxial cable and to all touchable conductive parts and circuits. Otherwise, there may be impermissibly high voltages on touchable parts in the event of a fault.

NOTICE

Damage to the device due to potential differences

To fully eliminate the influence of electromagnetic interference, the device must be grounded. There must be no potential difference between the following parts, otherwise the device or other connected device could be severely damaged:

- Housing of the SCALANCE W device and the ground potential of the antenna.
- Housing of the SCALANCE W device and the ground potential of a device connected over Ethernet.
- Housing of the SCALANCE W device and the shield contact of the connected Ethernet cable.

Connect both grounds to the same foundation earth or use an equipotential bonding cable.

Safety notices on use in hazardous areas

General safety notices relating to protection against explosion

WARNING

EXPLOSION HAZARD

Do not connect or disconnect cables to or from the device when a flammable or combustible atmosphere is present.

WARNING

EXPLOSION HAZARD

Do not press the reset button if there is a potentially explosive atmosphere.

WARNING

Unsuitable cables or connectors

Risk of explosion in hazardous areas

- Only use connectors that meet the requirements of the relevant type of protection.
- If necessary, tighten the connector screw connections, device fastening screws, grounding screws, etc. according to the specified torques.
- Close unused cable openings for electrical connections.
- Check the cables for a tight fit after installation.

 WARNING

Lack of equipotential bonding

If there is no equipotential bonding in hazardous areas, there is a risk of explosion due to equalizing current or ignition sparks.

- Ensure that equipotential bonding is available for the device.

 WARNING

Unprotected cable ends

There is a risk of explosion due to unprotected cable ends in hazardous areas.

- Protect unused cable ends according to IEC/EN 60079-14.

 WARNING

Improper installation of shielded cables

There is a risk of explosion due to equalizing currents between the hazardous area and the non-hazardous area.

- Ground shielded cables that cross hazardous areas at one end only.
- Lay a potential equalization conductor when grounding at both ends.

 WARNING

Insufficient isolation of intrinsically safe and non-intrinsically safe circuits

Risk of explosion in hazardous areas

- When connecting intrinsically safe and non-intrinsically safe circuits, ensure that the galvanic isolation is performed properly in compliance with local regulations (e.g. IEC 60079-14).
- Observe the device approvals applicable for your country.

Notes for use in hazardous locations according to ATEX, IECEx, UKEX and CCC Ex

If you use the device under ATEX, IECEx, UKEX or CCC Ex conditions you must also keep to the following safety instructions in addition to the general safety instructions for protection against explosion:

 WARNING

Transient overvoltages

Take measures to prevent transient surges of more than 40% of the rated voltage. Under no circumstances may transient surges exceed 119 V. This is the case if you only operate devices with SELV (safety extra low voltage).

 WARNING

Suitable cables at high ambient temperatures in hazardous area

At an ambient temperature of $\geq 60\text{ }^{\circ}\text{C}$, use heat-resistant cables designed for an ambient temperature at least $20\text{ }^{\circ}\text{C}$ higher. The cable entries used on the housing must comply with the IP degree of protection required by EN IEC / IEC 60079-0, GB/T 3836.1.

General notes on use in hazardous areas according to UL-HazLoc

If you use the device under UL-HazLoc conditions, you must also adhere to the following safety notices in addition to the general safety notices for protection against explosion:

 WARNING

WARNING - EXPLOSION HAZARD -

DO NOT DISCONNECT WHILE CIRCUIT IS LIVE UNLESS AREA IS KNOWN TO BE NON-HAZARDOUS.

 WARNING

Restricted area of application

This equipment is suitable for use in Class I, Division 2, Groups A, B, C and D or non-hazardous locations only.

 WARNING

Restricted area of application

This equipment is suitable for use in Class I, Zone 2, Group IIC or non-hazardous locations only.

6.2 Power supply

Note

Galvanic isolation of the power supply unit

To ensure dielectric strength according to IEEE 802.3, the supplying 24 V power supply unit must be galvanically isolated with a dielectric strength of 1500 VAC. The galvanic isolation must also not be bridged by other devices connected to the same power supply unit.


Note

All power supplies (24 V power supply unit or PoE) must not be connected to a mains supply higher than 300 V and the overvoltage category II.

Information on the power supply

- There are two options for the power supply:
 - Direct infeed via the four-pin M12 connection socket ①
The power supply can be connected redundantly. The inputs L1/L2 are decoupled. There is no distribution of load. The power supply unit with the higher output voltage supplies the device alone.
 - Power over Ethernet via the M12 Ethernet interface P2 ②.
The power supply cannot be connected redundantly.
- For the direct infeed of the power supply, use copper cables with the following properties:
 - Round cable cross-section with 6 to 8 mm diameter.
 - Two-wire cable with 0.5 to 1.5 mm² cross-section per wire.
 - Permitted tensile load at least 100 N. - UL
 - Listing of the cables according to the national installation regulations. In areas where NEC or CEC applies: Type PTLC or ITC
- To connect the functional ground, use a copper cable of category 20 AWG or a cable with a cross-section $\geq 0.75 \text{ mm}^2$.

Position and pin assignment



- ① M12 interfaces, A-coded
- ② M12 interface P2, D-coded
The power can also be supplied via this interface (Power over Ethernet).

The 4-pin M12 socket has the following pin assignment:

Pin	Signal	Assignment
1	L1+	24 VDC
2	L2+	24 VDC
3	M	Ground
4	M	Ground

Connecting/disconnecting the power supply

NOTICE
Turn off the power supply before you insert or remove the plug of the power supply.

1. Connect the connector and socket. Make sure that they lock in place correctly.
2. Tighten the knurled screw (torque 1 Nm).

Power over Ethernet

Note

Disabling the PoE power supply

Before you pull a plug via which the device is supplied with power using PoE, disable the relevant PoE power supply.

Note

"Phantom power" only with SCALANCE W778/W738

The device only supports the standard IEEE 802.3at/af Mode A. With this device, the connection to Ethernet is only possible using four-wire cables. For this reason, no PSE (Power Sourcing Equipment) can be used that only supplies the power via the free wire pairs.

Ethernet cables with M12 connectors for the SCALANCE W788-x M12 (Gigabit Ethernet, eight-wire) cannot be used for the SCALANCE W778/W738.

Note


No power sourcing equipment (PSE)

The device cannot be used as a PoE power supply for other devices.

6.3 Ethernet

For connection to Industrial Ethernet at 10/100 Mbps, the device has two M12 interfaces: D-coded, 4-pin.

Position and pin assignment



- ① M12 interface P1
- ② M12 interface P2
The power can also be supplied via this interface (Power over Ethernet).

The 4-pin connection socket has the following pin assignment:

Pin	Assignment
1	TX
2	RX
3	TX
4	RX

Connecting Ethernet ports

1. Connect the connector and socket. Make sure that they lock in place correctly.
2. Tighten the knurled screw (torque 1 Nm).

6.4 Antenna connector

The device has two antenna connectors of the type N-Connect located on the top of the device.




Figure 6-1 Antenna connectors

- ① Antenna connector R1 A1
- ② Antenna connector R1 A2

Procedure

Follow the steps below to connect a cable for an external antenna:

1. Remove the caps.
2. Insert the connector on the antenna cable into the N-Connect socket and screw the screw cap of the connector onto the socket (key size SW19, tightening torque 1.7 Nm).
3. If you only use one antenna, you need to connect this to the device via antenna connector R1 A1 ①.
4. Screw a terminating resistor to the unused antenna connector R1 A2 ② if you are only using one antenna.

Note

Terminating resistor

You can connect one or two external antennas to the WLAN interface. At the antenna connector R1A1, there must always be an antenna connected as soon as the WLAN interface is turned on. The unused antenna connector R1A2 must have a terminating resistor fitted; see Accessories (Page 23).

if no antenna is connected, the relevant interface must also be disabled for RX and TX. Otherwise, there may be transmission disruptions.

NOTICE
UL approval only for use in buildings
Within the area of authority of the NEC and CEC, the SCALANCE W778/W738 devices and the antennas connected to them may only be used in a closed building. For this reason, do not lead antennas into the outdoor area if you need to meet UL or CSA requirements.

Note

Cabinet installation

When installing the SCALANCE W device in a cabinet, you need to use detached antennas. A suitable flexible connecting cable for the connection between SCALANCE W and a detached antenna is available from SIMATIC NET. You will find detailed information in the section Accessories (Page 23).

6.5 Replacing the PLUG

Position


The PLUG slot is at the top of the device under a cover, see Reset button (Page 34).

NOTICE
Operating risk - Danger of data loss
Only pull and plug the PLUG when the device is de-energized.

Removing the PLUG

Follow the steps below to remove a PLUG from the device:

1. Turn off the power to the device.
2. Release the screw of the slot cover and swing the slot cover to the side.
3. Insert a screwdriver between the front edge of the PLUG (A) and the slot and release the PLUG.



4. Remove the PLUG from the slot.
5. Close the cover (tightening torque 0.8 Nm), to ensure that the device is closed and water and dust proof.

Note

Loss of the configuration

The reset button is directly beside the slot for the PLUG. The reset button cannot be used to remove the PLUG.


If you press and hold down the reset button you reset all the settings of the device to the factory defaults.

Inserting the PLUG

Follow the steps below to insert a PLUG in the device:

1. Turn off the power to the device.
2. The PLUG slot is on the top of the device housing under a cover, see Reset key (Page 34).
3. Release the screw of the slot cover and swing the slot cover to the side.

4. The housing of the PLUG has a protruding ridge on the long side (B). The slot has a groove at this position. Insert the PLUG correctly oriented into the slot. The PLUG is correctly inserted when it is completely inside the device and does not jut out of the slot.



5. Close the cover (tightening torque 0.8 Nm), to ensure that the device is closed and water and dust proof.

6.6 Grounding

EMC disturbances are diverted to ground via the functional ground. This ensures the immunity of the data transmission.

The grounding screw is identified by the following symbol for the functional ground .

Protective earth/functional ground

The connection of the reference potential surface with the protective earth system is normally in the cabinet close to the power infeed. This earth conducts fault currents to ground safely and according to DIN/VDE 0100 is a protective earth to protect people, animals and property from too high contact voltages.

Apart from the protective earth, there is functional grounding in the cabinet. According to EN60204-1 (DIN/VDE 0113 T1) electrical circuits must be grounded. The chassis (0 V) is grounded at one defined point. Here, once again the grounding is implemented with the lowest leakage resistance to ground in the vicinity of the power infeed.

With automation components, functional ground also ensures interference-free operation of a controller. Via the functional ground, interference currents coupled in via the connecting cables are discharged to ground.

Position


The functional ground is established via a grounding screw.

The connector for the grounding cable is located on the bottom of the device, see ⑤ of the device view. (Page 22)

Connecting up functional ground

Follow the steps below to connect the functional ground:

1. Put the grounding terminal ①, and the screw ② together as shown in the drawing.



- ① Grounding terminal with cable
- ② Screw (M4 thread) with spring washer and washer

2. Screw in the screw ② with a maximum tightening torque of 1.5 Nm.

Maintenance and cleaning

WARNING

Unauthorized repair of devices in explosion-proof design

Risk of explosion in hazardous areas

- Repair work may only be performed by personnel authorized by Siemens.
- For function checks, maintenance and servicing work, you need to observe the requirements on checking and maintaining plants in hazardous areas according to the standards EN / IEC 60079-17.

WARNING

Impermissible accessories and spare parts

Risk of explosion in hazardous areas

- Only use original accessories (Page 23) and original spare parts.
- Observe all relevant installation and safety instructions described in the manuals for the device or supplied with the accessories or spare parts.



CAUTION

Hot surfaces

Risk of burns during maintenance work on parts with a surface temperature above 70 °C (158 °F).

- Take appropriate protective measures, for example, wear protective gloves.
- Once maintenance work is complete, restore the touch protection measures.

NOTICE

Cleaning the housing

If the device is not in a hazardous area, only clean the outer parts of the housing with a dry cloth.

If the device is in a hazardous area, use a slightly damp cloth for cleaning.

Do not use solvents.

Upkeep and maintenance

8.1 Device configuration with PRESET-PLUG

Note the additional information and security notes in the operating instructions of your device.

NOTICE
Do not remove or insert a PLUG during operation
A PLUG may only be removed or inserted when the device is turned off.

Note**Support as of V6.0**

The PRESET-PLUG functionality is supported as of firmware version V6.0.

With the PRESET-PLUG, you can install the same device configuration (start configuration, user accounts, certificates) including the corresponding firmware on multiple devices.

The PRESET PLUG is write-protected.

You configure the PRESET PLUG using the Command Line Interface (CLI).

Creating a PRESET-PLUG

You create the PRESET PLUG using the Command Line Interface (CLI). You can create a PRESET-PLUG from any PLUG. To do this, follow the steps outlined below:

Note**Using configurations with DHCP**

Create a PRESET-PLUG only from device configurations that use DHCP. Otherwise, disruptions will occur in network operation due to multiple identical IP addresses.

You assign fixed IP addresses extra following the basic installation.

Requirement

- A PLUG is inserted in the device on which you want to configure the PRESET-PLUG functionality.

Procedure

1. Start the remote configuration using Telnet (CLI) and log on with a user with the "admin" role.
2. Switch to the global configuration mode with the command "configure terminal".
3. You change to the PLUG configuration mode with the "plug" command.

8.1 Device configuration with PRESET-PLUG

4. Create the PRESET-PLUG with the "presetplug" command.
The firmware version of the device and the current device configuration incl. user accounts and certificates are stored on the PLUG and the PLUG is then write protected.
5. Turn off the power to the device.
6. Remove the PRESET-PLUG.
7. Start the device either with a new PLUG inserted or with the internal configuration.

Procedure for installation with the aid of the PRESET-PLUG

1. Turn off the power to the device.
2. If it exists, remove the PLUG from the slot. You will find further information on this in the operating instructions of your device.
3. Insert the PRESET-PLUG correctly oriented into the slot. The PRESET-PLUG is correctly inserted when it is completely inside the device and does not jut out of the slot.
4. Turn on the power to the device again.
If there is a different firmware version on the device to be installed compared with that on the PRESET-PLUG, an upgrade/downgrade of the firmware is performed. You can recognize this by the red F-LED flashing (flashing interval: 2 sec on/0.2 sec. off). Afterwards the device is restarted and the device configuration incl. users and certificates on the PRESET-PLUG is transferred to the device.
5. Wait until the device has fully started up.
The red F-LED is off.
6. Turn off the power to the device after the installation.
7. Remove the PRESET-PLUG.
8. Start the device either with a new PLUG inserted or with the internal configuration.

Note

KEY-PLUG

If you have created the PRESET-PLUG from a KEY-PLUG, for operation with this configuration, you require an inserted KEY-PLUG.

IN this case before recommissioning the device you need to insert the relevant KEY-PLUG.

Note

Restore factory defaults and restart with a PRESET PLUG inserted

If you reset the device to the factory defaults, when the device restarts an inserted PRESET PLUG is formatted and the PRESET PLUG functionality is lost. You then need to create a new PRESET PLUG. The keys stored on the KEY-PLUG for releasing functions are retained.

We recommend that you remove the PRESET PLUG before you reset the device to the factory settings.

Formatting a PRESET-PLUG (resetting the preset function)

You format the PRESET PLUG using the Command Line Interface (CLI) to reset the preset function. To do this, follow the steps outlined below:

1. Start the remote configuration using Telnet (CLI) and log on with a user with the "admin" role.
2. Switch to the global configuration mode with the command "configure terminal".
3. You change to the PLUG configuration mode with the "plug" command.
4. Enter the command "factoryclean".
The PRESET-PLUG is formatted and the preset function is reset.
5. Write the current configuration of the device with the "write" command.

8.2 Restoring the factory settings

NOTICE
Previous settings
If you reset, all the settings you have made will be overwritten by factory defaults.

NOTICE
Inadvertent reset
An inadvertent reset can cause disturbances and failures in a configured network with further consequences.

With the reset button

When pressing the button, make sure you adhere to the instructions in the section "Reset button (Page 34)".

To reset the device to the factory defaults during the startup phase, follow the steps below:

1. Turn off the power to the device.
2. Loosen the screws of the cover.
3. Remove the cover.
4. Press the reset button and reconnect the device to the power supply while holding down the button.
5. Hold down the button until the red error LED "F" stops flashing after approximately 10 seconds and is permanently lit.
6. Release the button and wait until the fault LED "F" goes off.
The device starts automatically with the factory settings.
7. Close the cover (tightening torque 0.8 Nm), to ensure that the device is closed and water and dust proof.

With SINEC PNI

Follow the steps below to reset the device parameters to the factory settings with the SINEC PNI:

1. Select the device whose parameters you want to reset.
2. Click the "Reset device" button.
3. Select the "Reset to factory settings" option in the following dialog.

Via the configuration

You will find detailed information on resetting the device parameters using the WBM and CLI in the configuration manuals:

- Web Based Management, section "Restart"
- Command Line Interface, section "Reset and Defaults"

8.3 Firmware update via WBM or CLI not possible

Cause

If there is a power failure during the firmware update, it is possible that the device is no longer accessible using Web Based Management or the CLI.

When pressing the button, be sure to read the information in the "Reset button" section of the operating instructions.

Solution

You can then also assign firmware to a SCALANCE W using TFTP. Follow the steps below to load new firmware using TFTP:

1. Turn off the power to the device.
2. Now press the Reset button and reconnect the power to the device while holding down the button.
3. Hold down the button until the red fault LED (F) starts to flash after approximately 2 seconds.
4. Now release the button. The bootloader waits in this state for a new firmware file that you can download by TFTP.
5. Connect a PC to the SCALANCE W over the Ethernet interface.
6. Assign an IP address to the SCALANCE W with the SINEC PNI.
7. Open a DOS box and change to the directory where the file with the new firmware is located and then execute the command "tftp -i <ip address> PUT <firmware>". As an alternative, you can use a different TFTP client.
8. Close the cover to ensure that the device is closed and water and dust proof.

Note**Use of CLI and TFTP in Windows 10**

If you want to access the CLI or TFTP in Windows 10, make sure that the relevant functions are enabled in Windows 10.

Result

The firmware is transferred to the device.

Note

Please note that the transfer of the firmware can take several minutes. During the transmission, the red error LED (F) flashes.

Once the firmware has been transferred completely to the device, the device is restarted automatically.

See also

Reset button (Page 34)

Technical specifications

- SCALANCE W738-1 M12
- SCALANCE W778-1 M12
- SCALANCE W778-1 M12 EEC

Note

You will find detailed information on the transmit power and receiver sensitivity in the document "Performance data 802.11 abgn SCALANCE W770/W730" on the supplied data medium (REF_W770-RadioInterface.pdf).

Technical specifications		
Data transfer		
Ethernet transfer rate		10 / 100 Mbps
Wireless transmission rate		1 ... 300 Mbps
Wireless standards supported		IEEE 802.11a IEEE 802.11b IEEE 802.11g IEEE 802.11h IEEE 802.11n
Power supply for POE standards supported	Standards	IEEE 802.3af IEEE 802.3at
	Class	Class 2 (3.84–6.49 W)
	Mode	Mode A (phantom power)
Attachment to Industrial Ethernet		
	Quantity	2
	Design	M12 socket
	Properties	Half duplex/full duplex, autocrossover, auto-negotiation, autosensing, floating, PoE at port 2
Permitted cable lengths (Ethernet)	(Alternative combinations per length range)	
	IE TP torsion cable	0 ... 55 m 0 ... 45 m + 10 m TP cord
	IE FC TP marine cable	0 ... 85 m
	IE FC TP trailing cable	0 ... 75 m + 10 m TP cord
	IE FC TP flexible cable	
	IE FC TP standard cable	0 ... 100 m 0 ... 90 m + 10 m TP cord
Wireless interface		

Technical specifications			
Antenna connector	Quantity	2	
	Design	N-Connect socket	
	Impedance	50 Ω nominal	
Frequency range	2412 ... 2480 MHz 4920 ... 5875 MHz		
Electrical data			
Direct 24 VDC supply	Supply voltage from socket	24 V DC safety extra low voltage (SELV)	
	Permitted range	+/- 30 %	16.8 to 31.2 VDC
	Design	M12 socket	
	Properties	Electrically isolated, redundant design PoE to 24 VDC non-redundant design	
Supply voltage from PoE	Supply voltage	48 VDC	
	Permitted range	36 to 57 VDC	
Fusing	2 A / 24 VDC		
	1 A / 48 V DC PoE		
Current consumption	At 24 VDC / typical	250 mA (up to 350 mA @ 16.8 V)	
	With PoE / typical	125 mA (up to 150 mA @ 36 V)	
Power loss at 24 VDC	At 24 V DC / maximum	6 W	
	At 24 VDC / typical	3.6 W	
	With PoE / typical	6 W	
Permitted ambient conditions			
Ambient temperature	During operation	Non EEC variant	-20 °C to +60 °C
		EEC variant	-30 °C to +75 °C
	During storage		-40 °C to +85 °C
	During transportation		-40 °C to +85 °C
Relative humidity	During operation	≤ 95% at 25 °C, no condensation	
Operating altitude	During operation	≤ 2,000 m above sea level at max. 60 °C ambient temperature	
Contaminant concentration	According to IEC 60721		
Degree of pollution	2		
Degree of protection	IP65 (not tested by UL)		
Dimensions and weight			
Dimensions	W x H x D	140 x 160 x 45 mm (height without antenna connectors 149 mm)	
Weight	1040 g		
Installation options			
Direct	Wall mounting		
With additional holding plate	Mounting on a DIN rail		
	• with DIN rail mounting adapter		
	• with additional bracket support for installation rotated though 90°		

Technical specifications

Mean time between failure (MTBF)

at 40 °C ambient temperature


61 years

Dimension drawing

Note

Dimensions are specified in mm.

Front view



Width, height and dimensions for wall mounting

Side view



Figure 10-1 Side view W778 / W738

Approvals

You will find the approvals of the products in the reference work "Approvals SCALANCE W700 802.11n" on the Internet pages of Siemens Industry Online Support:

- Using the search function at Siemens Industry Online Support (<https://support.industry.siemens.com/cs/ww/en/>)
- Using the search function at Industrial communication (<https://support.industry.siemens.com/cs/ww/en/ps/15859/cert>)

Enter the entry ID of the relevant manual as the search item.

You will find the documentation for the SIMATIC NET products relevant here on the data storage medium that ships with some products:

- Product CD / product DVD
- SIMATIC NET Manual Collection
- SIMATIC NET IWLAN CD

Taiwan: NCC Statement SCALANCE W778-1/W738-1

Taiwan: NCC "WARNINGS" (Chinese)

NCC 警語:

第十二條

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信法規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

MPE 值如下：

WLAN 2.4GHz：電磁波曝露 MPE 標準值 $1\text{mW}/\text{cm}^2$ ，送測產品實測值為： $0.1848\text{mW}/\text{cm}^2$

WLAN 5GHz：電磁波曝露 MPE 標準值 $1\text{mW}/\text{cm}^2$ ，送測產品實測值為： $0.0287\text{mW}/\text{cm}^2$

Taiwan: NCC "WARNINGS" (English)

Article 12

Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery

Article 14

The application of low power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists.

The said legal communications means radio communications is operated in compliance with the Telecommunications Act. The low power radio-frequency devices must be susceptible with the interference from legal communications or ISM radio wave radiated devices. The operations near the radar system shall not be influenced. The directed antenna with high gain ($>6\text{dBi}$) must apply to the fixed point-to-point system only.

WLAN 2.4GHz

"MPE standard value is 1.0 mW/cm^2
Measured value is 0.1848 mW/cm^2 "

WLAN 5GHz

"MPE standard value is 1.0 mW/cm^2
Measured value is 0.0287 mW/cm^2 "

Professional installation

Installation and change of RF parameters must be done only by trained professional installers who ensure that the correct power and country settings are selected. Untrained personal shall not have access to the admin password in order to change these parameters.

Index

A

- Accessories, 23
- A-coded, 54
- Antenna cables, 25
- Antennas, 25, 56
 - Directional antenna, 28
 - Dual directional antenna with linear polarization, 28
 - Dual-band directional antenna with linear polarization, 28
 - Helical antenna, 28
 - MIMO antenna, 28
 - Omnidirectional antenna, 28
- Article numbers, 5

C

- Cables
 - Permitted lengths, 69, 70, 71
- Certification ID, 5
- Configuration manuals, 66
- Connecting
 - Antennas, 56
 - Ethernet, 55
 - Grounding, 59
 - Power supply, 54

D

- Documentation on the Internet, 5

E

- Ethernet, 55

F

- Factory default, 36
- Factory defaults, 65
- Factory setting, 65
- Functional ground, 59

G

- Grounding, 50, 59
- Grounding point, 59

I

- Interfaces, 69, 70, 71

L

- LED display, 30
- Lightning protection, 49
- Loading firmware, 36

P

- Power supply, 54
- Primary user (radar), 30

R

- Reset button, 34
- Reset device, 36, 65
- Restart of the device, 36

S

- Safety extra low voltage, 50
- Safety notices
 - for installation, 39
 - general, 9
 - Use in hazardous areas, 9, 39, 49
 - when connecting up, 49
- Scope of delivery, 22
- Scope of validity, 5

T

- Technical specifications, 69, 70, 71
- Type designations, 21

