Product	Article number
SINAMICS G120 CU240B-2 DP (firmware up to and including V4.7)	6SL3244-xxxx0-xPxx
SINAMICS G120 CU240E-2 DP (firmware up to and including V4.7)	6SL3244-xxxx2-xPxx
SINAMICS G120 CU240E-2 DP (firmware up to and including V4.7)	6SL3244-xxxx3-xPxx
SINAMICS G120 CU240S DP (firmware up to and including V3.2.x)	6SL324x-0BAxx-xPAx
SINAMICS G120 CU240S DP F (firmware up to and including V3.2.x)	6SL3244-0BA21-1PA0
SINAMICS G120 CU250S-2 DP Vector (firmware up to and including V4.7)	6SL3246-xxxx2-xPxx
SINAMICS G120C (firmware up to and including V4.7)	6SL3210-1KExx-xxPx
SINAMICS G120D CU240D DP (firmware up to and including V3.2.x)	6SL3544-0FA20-1PA0
SINAMICS G120D CU240D DP F (firmware up to and including V3.2.x)	6SL3544-0FA21-1PA0
SINAMICS G120D CU240D-2 DP (firmware up to and including V4.7)	6SL3544-xxxx0-xPxx
SINAMICS G120D CU240D-2 DP-F (firmware up to and including V4.7)	6SL3544-xxxx1-xPxx
SINAMICS G120D CU250D-2 DP-F (firmware up to and including V4.7)	6SL3546-xxxx1-xPxx
SINAMICS G130 CU320 (firmware up to and including V2.6.2)	6SL3040-0xA00-0xxx
SINAMICS G130 CU320-2 DP (firmware up to and including V4.8)	6SL3040-1MA00-0xxx
SINAMICS G150 CU320 (firmware up to and including V2.6.2)	6SL3040-0xA00-0xxx
SINAMICS G150 CU320-2 DP (firmware up to and including V4.8)	6SL3040-1MA00-0xxx
SINAMICS GL150 CU320 (firmware up to and including V2.6.2)	6SL3040-0xA00-0xxx
SINAMICS GL150 CU320-2 DP (firmware up to and including V4.5)	6SL3040-1MA00-0xxx
SINAMICS GM150 CU320 (firmware up to and including V2.6.2)	6SL3040-0xA00-0xxx
SINAMICS GM150 CU320-2 DP (firmware up to and including V4.5)	6SL3040-1MA00-0xxx
SINAMICS S110 CU305 DP (firmware up to and including V4.4)	6SL3040-0JA00-0AAx
SINAMICS S120 CU310 DP (firmware up to and including V2.6.2)	6SL3040-0xA00-0xxx
SINAMICS S120 CU320 (firmware up to and including V2.6.2)	6SL3040-0xA00-0xxx
SINAMICS S120 CU320-2 DP (firmware up to and including V4.8)	6SL3040-1MA00-0xxx