

## 9.4 UCN Spare Parts

### UCN Parts list

The UCN spare parts are listed in Table 9-4 for reference. This same list of spare parts can also be found in the High-Performance Process Manager Service or Logic Manager Service manual. Information about the use of these parts can be found in the Process Manager/Advanced Process Manager Installation, Universal Control Network Planning, or Universal Control Network Installation manuals.

**Table 9-4 UCN Parts List**

Name	Description	Part Number
UCN Drop Cable	RG-6 UCN drop cable (pair) 0.5 meter	51195153-900
	1.5 meter	51195153-901
	2.0 meters	51195153-002
	2.5 meters	51195153-902
	3.5 meters	51195153-903
	4.5 meters	51195153-904
	5.0 meters	51195153-005
	10 meters	51195153-010
	20 meters	51195153-020
	30 meters	51195153-030
	40 meters	51195153-040
	50 meters	51195153-050
UCN Trunk Cable	RG-11 UCN trunk cable (pair)—internal application	51195199-xxx
	2.6 meters	51195199-002
	5.2 meters	51195199-005
	10.4 meters	51195199-010
	20.8 meters	51195199-020
	31.2 meters	51195199-030
	52.0 meters	51195199-050
	101.4 meters	51195199-100
	200.2 meters	51195199-200
	400.4 meters	51195199-400
	600.6 meters	51195199-600
UCN Trunk Cable	UCN trunk cable RG-11—external application (xxx meters, 762 to 1524 meters)	511951607-xxx

	152.4 meters	51191607-152
	304.8 meters	51191607-305
	762.0 meters	51191607-762
UCN Trunk Cable	UCN trunk cable RG-11 — internal application	51190899-xxx
UCN Trunk Tap	2-Drop tap assembly kit (pair)	51201394-100
	4-Drop tap assembly kit (pair)	51201395-100
	8-Drop tap assembly kit (pair)	51109485-100
UCN Tap Terminator	UCN tap terminator	51190782-100