



5-IN-1 STYLE BLADE
CORDLESS ANIMAL CLIPPER

Pet Clipper
专业宠物电推剪

CLIPPER SPECIFICATIONS

Model	PGC-780
Input	5V=1A 8W Max
Lithium Battery	3.7V 2600mAh
Charge Time	150 minutes
Run Time	240 minutes
Speed	5000-5500-6000-6500-7000 SPM
Noise	≤ 65 dB
Package Includes	Clipper USB Type-C Cable - 2.4m / 7.9feet. Cleaning Brush Lubricant Oil - 8ml / 0.27oz Manual

Accessories:




①

USAGE


Push the switch lever and adjust it to the desired speed position to use the clipper.

- When the battery level is sufficient, the clipper can be operated cordless.
- When the battery level is very low or there is no time to charge the clipper, it can be temporarily operated with a cord like the corded version.

* The battery will be charged simultaneously when the clipper operated with a cord.



Blade Length Adjustment Operation



②


CHARGING INSTRUCTION

PGC-780 support working with cord and cordless, to meet the demands of long working hours. Cordless using is more convenient.

The clipper can be charged by charging cable and your power adaptor.

When fully charged, please remove the charging cable.
Remaining power from 0% to 100% takes only 150 minutes, convenient for you to use at any time.


During using the clipper with cord, it can be charged at the same time.



③


DISPLAY

LCD DISPLAY




Continuously use for 30mins, keeps flashing, turn off the machine, then clean and oil.

POWER DISPLAY ON CORDLESS MODE



POWER DISPLAY ON CORDED MODE



④

MAINTAINING BLADES


CAUTION:

Turn OFF the clipper and disconnect from outlet before performing maintenance.

BLADE REMOVAL, MAINTENANCE AND INSTALLATION


◆ BLADE REMOVAL

Hold the clipper face up with one hand and press the blade down with thumb, then remove the blade into the other hand to avoid dropping the blade.



◆ BLADE MAINTENANCE


1. Blade cleaning: Press and hold the top of the shear blade. Use the cleaning brush to clean hair between the shear blade and the fixed blade.



⑤

MAINTAINING BLADES


2. Blade oiling: Use 1-2 drops of lubricating oil on the 5 points shown below.



Do not detach the blade spring while maintaining to avoid malfunction.

◆ BLADE INSTALLATION

Hold the clipper face down with one hand and place the bottom of the blade aligning the middle of the blade with the clipper. Push the front of the blade down until it snaps into place.



⑥

OPTIONAL BLADE SERIES

Material

Comb blade: Stainless steel

Shear blade: Titanium coating ceramic

Item: #0490



Coarse blade: 0.7 - 1.3 - 1.9 - 2.5 - 3.0 mm

Size adjustable: 30 - 15 - 10 - 9 - 8

Item: 0506



Fine blade: 0.5 - 1.0 - 1.6 - 2.2 - 2.8 mm

Size adjustable: 40 - 30 - 15 - 10 - 9

⑦

OPTIONAL ACCESSORIES

STAINLESS STEEL ATTACHMENT GUIDE COMBS KIT

Model: ACK-002 (Item: #6645)

Work perfectly with SHERNBAO 5-in-1 Stainless Steel Attachment Guide Combs for additional cut lengths.

* Please adjust the FINE blade to the "40" position when using combs.
* Please adjust the COARSE blade to the "30" position when using combs.

ONLY can be used on smoothly brushed hair.

1/8" - 3mm

1/4" - 6mm

3/8" - 10mm

1/2" - 13mm

5/8" - 16mm

3/4" - 19mm

7/8" - 22mm


1" - 25mm

⑧

产品规格

型 号	PGC-780
输 入	5V=1A 8W Max
电 池	3.7V 2600mAh
充电时间	150 分钟
续航时间	240 分钟
转 速	5000-5500-6000-6500-7000 SPM
噪 音	≤ 65 dB
主机以及附件	电推剪 USB Type-C 充电线 - 2.4m 清洁刷 润滑油 - 8ml 说明书

Accessories:




⑨

使用方法


打开开关，即可使用该理发器。

- 当电量充足时，电推剪可无线使用。
- 当电量极低或没有时间给电推剪充电时，可像有线款电推剪一样临时连接电源线使用。

* 连接电源线使用电推剪时，电池会同时充电。



Blade Length Adjustment Operation



⑩

充电说明

PGC-780 支持有线和无线使用，以满足长时间工作的需求。无线使用更为便捷。

可用充电线和电源适配器为该电推剪充电。

充满电后，请拔下充电线。

电量从 0% 充至 100% 仅需 150 分钟，方便您随时使用。


在使用有线理发器时，它也可以同时充电。



⑪


LCD 屏幕功能说明

● LCD 屏幕显示



连续使用 0.5h 时，持续闪烁，关机后加油再开机，指示灯熄灭。

● 充电显示



充电时加油指示灯和充电指示灯同时熄灭。

当电量小于 5% 时，电量指示灯 100% 和充电指示灯同时闪烁，当电量耗尽所有指示灯熄灭。

注意：请勿私自拆卸或更改电池，否则可能导致主机系统无法识别，导致主机无法正常使用等。

⑫

刀头维护

注意事项:

在进行维护前，请关闭电推剪并断开电源。


刀头拆卸、维护与安装

如图所示，用右手大拇指向后推动刀头，左手保护以免刀头跌落并损坏。




如图所示用清洁刷清洁刀头，按住刀片顶部机构，清洁上下刀片之间残留的毛发。

(请不要分解刀头弹簧，可能会引起故障)




⑬

清洁完后如图所示在刀头 5 个位置注入 1-2 滴滴润滑油，



然后重新装入刀头。

(对准槽位在装入时必须听到“咔哒”声才能确定完全装上)



⑭

可选刀头系列

5-IN-1 系列刀头

刀头材质:

动刀片: 陶瓷镀钛

定刀片: 钢


Item: 0490



雷毛长度: 0.7 - 1.3 - 1.9 - 2.5 - 3.0 mm

可调节尺寸: 30 - 15 - 10 - 9 - 8

Item: 0506



雷毛长度: 0.5 - 1.0 - 1.6 - 2.2 - 2.8 mm

可调节尺寸: 40 - 30 - 15 - 10 - 9

⑮

可选套梳系列

八合一不锈钢套梳

Model: ACK-002 (Item: #6645)

完美适用于 SHERNBAO 5 合 1 刀头
不锈钢套梳可提供多种雷毛长度选择，
修剪更多丰富的美容造型。

* 使用套梳时，请将 5-IN-1 系列 FINE 刀头调整到“40”位置。
* 使用套梳时，请将 5-IN-1 系列 COARSE 刀头调整到“30”位置。

注: 请给宠物洗澡吹干后使用体感更佳。

1/8" - 3mm

1/4" - 6mm

3/8" - 10mm

1/2" - 13mm

5/8" - 16mm

3/4" - 19mm

7/8" - 22mm

1" - 25mm

⑯