

1:1印刷文件

封底



武汉神宝宠物用品有限公司

WUHAN SHERNBAO PET PRODUCTS MANUFACTURING CO., LTD.

WWW.SHERNBAO.COM

© 2019

P/N.: 22920.24.01.00.1 VER.:V1.3

内页一

This is a top grade professional dryer, which designed with high-tech digital system adjusting wind speed and temperature smartly.

With bigger Anion generator inside, effectively reducing static.

High-tech well distributed heat make pet hair protected.

Except completely drying hair, it furtherly made hair fluffy, plentiful naturally.

Especially recommend to professional grooming shops for business use.

Stand and wall-hanging type are flexible to fix diffuser in optimum position, quite convenient, release groomer' hands to focus on grooming and modeling, extremely time-saving and efficiency improved.

For better using, PLEASE DO sturdily install this machine in accordance with this Manual, follow rules as below before powered on.

- For better using, PLEASE DO sturdily install this machine according to this instruction, follow rules as below before powered on.
1. Please check and make sure your voltage and Max load current same as requested of this product.
 2. Please clear hair/fur on filter sponge before power on.
 3. Please turn switches in low-end for wind speed and temperature, to avoid sudden strong outlet once power on. (May adjust or increase freely after then as required.)
 4. This hairdryer must be fixed out of reach of a person taking a bath or shower.
 5. The appliance must be fixed so that the hand held part, when fully extended, is out of reach of a person taking a bath or shower.

Technical parameter

Wind speed	max 20.5m/sec
Air Volume	6.9m³/min
Temperature	MAX:Room Temperature + 60 C (140°F)
Power	220~240V 1800W MAX 110~127V 1700W MAX
Motor Lifetime	≥5000hrs
Max emission sound pressure	<70dB(A)


Different voltage condition, different current required, please refer to this sheet.

Voltage condition (Volt)	Require Minimum load current (Amperes)
AC220-240V 60Hz	Not lower than 10A
AC110-127V 60Hz	Not lower than 15A

封面



User Manual



PSD-920P

Stand Dryer


PWD-921P

Wall-mount Dryer

内页二

NOTICE


1. This appliance is not intended for use (including maintenance such as cleaning) by persons (including children aged from 8 years and above) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off
4. For additional protection, the installation of a Residual Current Device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.
5. This hairdryer must be fixed out of reach of a person or pets taking a bath or shower.
6. The appliance must be fixed so that the hand-held part, when fully extended, is out of reach of a person or pets taking a bath or shower.
7. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
8. WARNING- Do not use this appliance near water in bathtubs, basins or other vessels containing water!
9. Please dear hairfur on filter sponge before power on every time.
10. When the appliance operated, a trained person must watch over the pets to avoid injury to the pets or injury to person by frightened pets
11. disconnect the appliance from its power source during service and maintenance
12. the removal of the plug has to be such that an operator can check from any of the points to which he has access that the plug remains removed
13. This appliance is designed to be used in commercial areas
14. The appliance must have a separate power supply line. Do not use electricity with other high-power equipment.
15. Do not insert any metal objects into the gaps of the appliance, nor allow any liquid to drip into it. Otherwise, it may cause electric shock personal injury or short-circuit of the appliance.
16. Do not cover, wrap, block the air outlet and air inlet to avoid damage to the appliance.
17. If there is a malfunction during the use of the appliance, please disconnect the power of the host in time and send it directly to Shenbao's designated after-sales service center for professional maintenance. DO NOT disassemble the appliance by yourself. Otherwise, Shernbao company and our distributors are NOT responsible for any losses caused by this.
18. Please install and use the corresponding stand bracket or wall-mount bracket in strict accordance with this manual.



内页三


Installation of wall-mounted arm

1. REQUEST FOR WALL
The wall must be strong enough to support the arm assembly and machine body.
2. REQUEST FOR HEIGHT
Wall height: ≥240cm(94.5 inch)
Height from bracket to floor: 184/195cm(72.5/76.8 inch)





Mounted to the ceiling

Hollow wall, or not enough height, or several sets machines required in one room, you may install machines to ceiling as another option (refer to this illustration). You can make ceiling bracket by yourself or buy and consult from distributors of Shernbao.



Installation of wall plate

Refer to Pictures as below, drill 3 holes same position as the Wall plate, fix this plate on the wall by setscrews, and then hanging arm installed to the wall plate.




Note: Make sure that the fixing plate is installed horizontally, and ensure the wall is vertical to the ground, otherwise the machine will rotate automatically.

内页四

Instruction for installation


Suggestion:
Carefully check" Supporting Arm" sturdily mounted in machine, as to avoid unnecessary injury.



内页五

Cautions for daily Maintaining

- Attention:
- While daily maintaining, make sure machine is powered off.
1. Please regularly clean the filter sponge for air entry, at least once a day for business user.
STEP to clean: power off—counter-clockwise take out the" bolt" and net—take out " Filter Sponge" —clear hair etc. —clean " Filter Sponge & Air entry net" (If they must be washed by water, Dry every component before re-assembly).
 2. Clean its surface by soft cloth, do not use neutral cleanser, if not, may lead defaced.




Operation Introduction

Turn on the power switch before use.

Wind speed & Temperature adjustment
Controlled by a precision adjustable resistance switch, turn clockwise to higher, counter clockwise to lower.
Notice: When the knob is adjusted to the end, do not continue to use force to avoid damaging the switch knob.

Notice: If the minimum wind speed and maximum temperature are setting, after continuous use for a long time, the dryer may automatically cut off the heating unit when the air flow temperature is too high to avoid scald the skin and hair.
When the air flow temperature drops to a safe range, the heating unit will re-start automatically.
This is just for safety, not a malfunction.



内页六

Scaffolding blower assembly diagram

